

Serve the world



FTTH
Terminal Box

Shenzhen UnitekFiber Solution Limited

sales@unitekfiber.com

Tel: +86 0755-21034367


Office Add: 8F, Datang Shidai Building, No. 2203 Meilong Road
Longhua District, Shenzhen, China

Shenzhen UnitekFiber Solution Limited

Fiber Optic Distribution Box



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-001A	167*102*31MM	159*80MM	2 Core	Wall mounting(indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-001B	186*116*40MM	D:195MM	4 Core	Wall mounting (indoor/outdoor)



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-001C	186*116*40MM	D:195MM	6 Core	Wall mounting (indoor/outdoor)



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-002A	191*120*44MM	185*93MM	4 Core	Wall mounting(indoor/outdoor) Pole mounting




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-002B	213*163*47MM	206*129MM	8 Core	Wall mounting (indoor/outdoor)




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-003A	186*116*40MM	D:195MM	6 Core	Wall mounting (indoor/outdoor)


Fiber Optic Distribution Box



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-004A	260*230*70MM	245*100MM	12 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-005A	205*180*50MM	150*190MM	12 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-006A	225*200*65MM	168*210MM	12 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-006B	225*200*65MM	168*210MM	8 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-007A	320*240*100MM	190*298MM	24 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-007B	320*240*100MM	190*298MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-008A	253*258*92MM	60*113MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-008B	253*258*92MM	60*113MM	24 Core	Wall mounting (indoor/outdoor) Pole mounting

Fiber Optic Distribution Box

5



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-009A	308*265*120MM	70*255MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-009B	308*265*120MM	70*255MM	24 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size)	Max Capacity	Way to install
UN-CXSJ-010A	330*260*130MM	200*260MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-010B	330*260*130MM	200*260MM	24 Core	Wall mounting (indoor/outdoor) Pole mounting

6




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-011A	420*320*132MM	256*400MM	32 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-011B	420*320*132MM	256*400MM	48 Core	Wall mounting (indoor/outdoor) Pole mounting




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-012A	347*275*115MM	70*315MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-012B	347*275*115MM	70*315MM	24 Core	Wall mounting (indoor/outdoor) Pole mounting

Fiber Optic Distribution Box

7



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-013A	410*340*132MM	70*387MM	32 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-013B	410*340*132MM	70*387MM	48 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-014A	245*203*69MM	77*72MM	8 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-015A	320*260*95MM	83*157MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-015B	320*260*95MM	83*157MM	16 Core Install <u>splitter</u>	Wall mounting (indoor/outdoor) Pole mounting




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-016A	210*220*55MM	80*70MM	8 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-017A	320*260*95MM	83*157MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting

8


Fiber Optic Distribution Box




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-018A	380*260*114MM	60*270MM	24 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-018B	380*260*114MM	60*270MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-019A	550*390*193MM	60*415MM	64 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-019B	550*390*193MM	60*415MM	92 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-020A	250*190*72MM	130*82MM	8 Core Install splitter	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-020B	250*190*72MM	130*82MM	12Core	Wall mounting (indoor/outdoor) Pole mounting




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-021A	295*220*85MM	155*82MM	16 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-021B	295*220*85MM	155*82MM	16 Core Install splitter	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-022A	340*250*110MM	154*82MM	24 Core	Wall mounting (indoor/outdoor) Pole mounting

Fiber Optic Distribution Box



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-023A	379*293*115MM	132*400MM	24 Core	Wall mounting (indoor/outdoor) Pole mounting
UN-CXSJ-023B	379*293*115MM	132*400MM	32 Core	Wall mounting (indoor/outdoor) Pole mounting



(Model NO	Overall Size	Installation Size)	Max Capacity	Way to install
UN-CXSJ-024A	385*245*130MM	D:190MM	96 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-025A	385*245*130MM	D:190MM	96 Core	Wall mounting (indoor/outdoor) Pole mounting




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-026A	385*245*155MM	D:190MM	144 Core	Wall mounting (indoor/outdoor) Pole mounting



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-027A	395*245*130MM	D:190MM	288 Core	Wall mounting (indoor/outdoor) Pole mounting

Fiber Optic Distribution Box




Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-101A	150*110*33MM	132*50MM	4 Core	Wall mounting (indoor/outdoor)



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-102A	150*110*48MM	132*50MM	8 Core	Wall mounting (indoor/outdoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-104	12*12*110MM	Fibers 1pcs	Wall mounting (indoor)



Model NO	Overall Size	Installation Size	Max Capacity	Way to install
UN-CXSJ-103A	315*160*55MM	212*115MM	12 Core	Wall mounting (indoor/outdoor)
UN-CXSJ-103B	340*240*55MM	265*178MM	24 Core	Wall mounting (indoor/outdoor)
UN-CXSJ-103C	340*240*90MM	265*178MM	48 Core	Wall mounting (indoor/outdoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-105	18*11*85MM	Fibers 2pcs	Wall mounting (indoor)

Fiber Optic Distribution Box

15



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-106	18*11*85MM	Fibers 1pcs	Wall mounting (indoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-107	48*10*95MM	Fibers 2pcs	Wall mounting (indoor)

16



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-108	100*80*22MM	2 Core	Wall mounting (indoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-109	86*86*27MM	2 Core	Wall mounting (indoor)

Fiber Optic Distribution Box



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-110	86*86*27MM	2 Core	Wall mounting (indoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-111	86*86*27MM	2 Core	Wall mounting (indoor)




Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-112	160*48*18MM	1 Core	Wall mounting (indoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-113	135*86*20MM	1 Core	Wall mounting (indoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-114	135*86*20MM	2 Core	Wall mounting (indoor)




Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-115	115*86*23MM	1 Core	Wall mounting (indoor)

Fiber Optic Distribution Box



19

Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-116	84*130*24MM	2 Core	Wall mounting (indoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-117	123*80*27MM	2 Core	Wall mounting (indoor)



20

Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-118	105*82.5*22.5MM	2 Core	Wall mounting (indoor)



Model NO	Overall Size	Max Capacity	Way to install
UN-CXSJ-119	100.5*80.5*28.5MM	4 Core	Wall mounting (indoor)